



# BR-WX-1

## WX-1 In-Ceiling/In-Wall Bracket



### INSTALLATION GUIDE

# Package contents

- BR-WX-1 In-Ceiling/In-Wall Bracket
- *Installation Guide*
- Installation screws

## BR-WX-1


The BR-WX-1 In-Ceiling/In-Wall Bracket is designed to mount the WX-1 directly into any wall or ceiling.

**Important:** Read all instructions before attempting to install the bracket.


# BR-WX-1 mounting

To install the bracket:


- 1 Press down on the AP bracket to release the AP bracket from the push latches on the in-ceiling bracket.




- 2** Swing the AP bracket out from the in-ceiling bracket.



- 3** Slide both hinge arm locks towards the inside of the in-ceiling bracket to the open position.




- 4** Press the hinge arms towards the center of the AP bracket to release the hinge pins from the hinge mounting holes on the in-ceiling bracket. While holding the hinge arms inward, slide the AP bracket out from the In-ceiling bracket.




- 5 Place the WX-1 into the AP bracket as shown, then secure it with the provided screws.

**Note:** Install the AP bracket such that the LAN/Reset/DC/Kensington lock ports are aligned with their respective labels on the AP bracket.




- 6** Using the supplied template, cut a 10 1/4" x 7 5/8" rectangle at the desired mounting location for your WX-1.
- 7** Route an in-wall Ethernet cable through the opening of the in-ceiling bracket, then insert the in-ceiling bracket into the cutout.






- 8 Use a Phillips screwdriver to tighten the mounting ears.




**Note:** Do not use excessive force when tightening the mounting ears, or the mounting ear threads may become stripped.

- 9** Plug an Ethernet cable into the WX-1, then press the hinge arms towards the center of the AP bracket.




- 10** While holding the hinge arms inward, insert the AP bracket/WX-1 assembly into the in-ceiling bracket.
- 11** Align the hinge pins on the hinge arms with the hinge mounting holes on the in-ceiling bracket, then release the hinge arms. Make sure that the hinge pins are fully inserted into the hinge mounting holes and the AP bracket/WX-1 assembly is able to swing freely.


- 12** Slide both hinge arm locks away from the in-ceiling bracket to the closed position.



Hinge arm lock  
closed position



- 13** Swing the AP bracket/WX-1 assembly into the in-ceiling bracket until the AP bracket is secured to the two push latches. An audible click will be heard when the AP bracket is secured to the push latch.




**Note:** Make sure the hinge arm locks are in their closed position before swinging the AP bracket/WX-1 assembly into the in-ceiling bracket.

# Installation with optional pre-construction bracket


(Pre-construction bracket sold separately)

- 1** Place the pre-construction bracket against the bottom of the ceiling studs at the desired mounting location, then mark locations for the mounting screws.
- 2** Drill 1/16" pilot holes at the marked locations, then secure the pre-construction bracket to ceiling studs using the provided hardware. (Note: The Pakedge logo should face out.)
- 3** Install sheetrock over the pre-construction bracket. Make note of where the cutout on the pre-construction bracket is when installing the drywall.
- 4** Cut an opening in the sheetrock using the cutout on the pre-construction bracket as a guide.




## Accessing WX-1 LAN/Reset


- 1 Press the center of the WX-1 in towards the ceiling/wall until the AP bracket has been released from the two push latches. An audible click can be heard when the push latches are released.




- 2** After the AP bracket has been released from the push latches, swing the WX-1 out from the in-ceiling bracket.



- 3** Slide the hinge arm locks towards the inside of the in-ceiling bracket to the open position.




Hinge arm lock  
open position





- 4 Press the hinge arms towards the center of the AP bracket to release the hinge pins from the hinge mounting holes on the in-ceiling bracket.
- 5 While holding the hinge arms inward, slide the AP bracket out from the in-ceiling bracket to access the LAN port and Reset button.



**Note:** Follow the “Mounting” section’s Steps 9-13 to insert the AP bracket/WX-1 assembly back into the in-ceiling bracket.

# Technical Support

For technical help:  
[www.pakedge.com/portal](http://www.pakedge.com/portal)  
[support@pakedge.com](mailto:support@pakedge.com)  
(650) 385-8703

For regulatory information:  
[www.pakedge.com/regulatory](http://www.pakedge.com/regulatory)



11734 S. Election Road  
Draper, UT 84020  
Main: (650) 385-8700 Fax: (650) 685-5520

[www.pakedge.com](http://www.pakedge.com)  
[sales@pakedge.com](mailto:sales@pakedge.com)  
©2018 Control4. All rights reserved.

Latest version at  
[pkdge.co/brwx1-qsg](http://pkdge.co/brwx1-qsg)



QSG-A001-01A-C 2018-09-06 MS